




# Panasonic KX-E603 Printwheel Replacement

This guide will demonstrate how to replace the printwheel in your Panasonic KX-E603 Electronic Typewriter.

Written By: Lindsay Stratis



## INTRODUCTION

This guide will demonstrate how to replace the printwheel on your typewriter, step-by-step.

## Step 1 — Ink Cartridge



- Open the lid of the typewriter.

## Step 2



- To release the green locking lever, pull it towards you.




### Step 3



- Gently lift to remove the old ink cartridge.

### Step 4 — Printwheel



- Firmly grasp either one, or both of the plastic printwheel ends protruding from the carriage as seen.
- Gently lift the printwheel while slightly pushing forward to remove the printwheel from its housing.

To reassemble your device, follow these steps in reverse using your new printwheel.

This document was last generated on 2017-09-29 03:53:26 PM.